

HY6E/HY6G/HY3E DELIMING INFORMATION

Regular deliming, depending on your steamer usage and local water quality, must be done to enhance performance and prolong the life of your HyPerSteam™ convection steamer. Steamer must be turned off after every use to prevent lime scale buildup—do not run steamer continuously. **ALWAYS USE HOT PADS OR MITTS WHEN HANDLING HOT STEAMER PANELS OR RACKS.**

RECOMMENDED TOOLS & CLEANERS:

- Groen Delimer/Descaler (Part Number 114800). **Do NOT use any product containing chlorides or sulfamic acid, including hydrochloric acid.**
- Nylon scrub pad, cloth and/or sponge

DELIMING STEPS (Use Touch Pad):

- STEP 1 Press ON/OFF to turn steamer off. Open door(s).
- STEP 2 **Let cavity cool for 5 minutes or longer.** While cool, wipe out cavity. Drain holes at rear of cavity must be clear of debris. Close door(s).
- STEP 3 Press and hold CLEAN while turning steamer on pressing ON/OFF, until only DELIME and POWER lights remain on (all lights will turn on, then off, except DELIME and POWER).
- STEP 4 After 5 minutes, beeper will beep rapidly, signaling you to add Groen Delimer/Descaler. Door(s) must remain closed for entire delime cycle.
- STEP 5 Pour 1 pint (2 cups) of delimer PER CAVITY into upper and/or lower delimer drawer(s) or port(s). Press CLEAN. Double-stacked unit cavities may be delimed together or separately.
- STEP 6 Delime cycle will start, taking about 30 minutes. When delime cycle is complete, DELIME light will appear, DONE light will flash and beeper will beep.
- STEP 7 Press ON/OFF to turn steamer off. **Let cavity cool for 5 minutes or longer.** Open door(s), wipe out inside of cavity and wipe door gasket.
- STEP 8 To use steamer, press ON/OFF. When READY light appears, steamer is ready to use.

NOTES:

- If DELIME light flashes rapidly (5 times per second), press CLEAN to restart delime cycle.
- If power outage occurs during deliming, delime cycle must be restarted. Press CLEAN.
- **For best performance, do not interrupt delime cycle.** If delime cycle must be stopped, press ON/OFF to turn off. **Let cavity cool for 5 minutes or longer.** Press ON/OFF to turn on. Set timer for 5 minutes. After beeper beeps, press ON/OFF to turn off. **Let cavity cool for 5 minutes or longer,** carefully open door(s) and wipe out cavity completely.